




Cross drill/milling unit



Item No.	Machine Interface			Tool Interface	Dimensions/technical data						
	D	Machine(s)	Drive		d	LPR	LF	e	n max. [rpm]	M [Nm]	i n1:n2
NF16-DNE-CT31A-063-E-A	31	Cincom A20 Cincom L20	Spur gear	ER-16NF	0.5-10	63.5	52	54	8000	13	1:1

Dimensions in mm. Including clamping nut and plug screw ER-16NF.

3-spindle Face drill/milling unit




Item No.	Machine Interface			Tool Interface	Dimensions/technical data									
	D	Machine(s)	Drive		d	LF1	LF2	LF3	WPR	WF	e	n max. [rpm]	M [Nm]	i n1:n2
NF16-DNI-CT31A-076-E-X3-A	31	Cincom A20 Cincom L20	Spur gear	ER-16NF	0.5-10	136.5	106.5	76.5	33	44.5	50.5	8000	6	1:1




Dimensions in mm. Including clamping nut and plug screw ER-16NF.

Cylindrical shank holder

with cylindrical shank and flat.

For flexible use of ER collets and nanoFlex® adapters in boring bar and sleeve holders.



Size	Item No.	DMM	d min.	d max.	LF	LPR	OAL	d ₁	m	e			
ER-16NF	NF16-SSH-075-A	3/4"	0.5	10	17	28.5	78.5	10.5	G1/8"	60.5	NF16-SCN-A	107520005	NF16-SPL-A

Dimensions in mm. Including clamping nut and plug screw ER-16NF.

Starter Set

NF16-DNE-CT31A-063-E-SK-A

Includes:

- 1 NF16-DNE-CT31A-063-E-A Cross drill/milling unit
- 1 NF16-SAD-ER11-A Collet chuck adapter with ER11M
- 1 NF16-SDR-A Drive ring (incl. NF16 Clamping screw)
- 1 NF16-STW-A Torque screwdriver
- 1 107516002 Spanner wrench SW19
- 1 107520005 Spanner wrench ER-16NF
- 1 107511005 Spanner wrench ER11M

